

Operator's Manual PP019 and PP020 Passive Probes



700 Chestnut Ridge Road Chestnut Ridge, NY, 10977-6499 Tel: (845) 425-2000, Fax: (845) 578 5985 teledynelecroy.com

PP019 and PP020 Passive Probes Operator's Manual

© 2017 Teledyne LeCroy, Inc. All rights reserved.

Unauthorized duplication of Teledyne LeCroy documentation materials is strictly prohibited. Customers are permitted to duplicate and distribute Teledyne LeCroy documentation for internal educational purposes.

Teledyne LeCroy is a registered trademark of Teledyne LeCroy, Inc. Other product or brand names are trademarks or requested trademarks of their respective holders. Information in this publication supersedes all earlier versions. Specifications subject to change without notice.



This electronic product is subject to disposal and recycling regulations that vary by country and region. Many countries prohibit the disposal of waste electronic equipment in standard waste receptacles. For more information about proper disposal and recycling of your Teledyne LeCroy product, visit teledynelecroy.com/recycle.

928605-00 Rev A July, 2017

Terms and Symbols

The following symbols appear on the product or in its documentation:

| 4 | WARNING | High Voltage. Risk of electric shock or burn. | | | | |
|----------|-----------------------------|---|--|--|--|--|
| <u>^</u> | WARNING or CAUTION | Condition or practice could result in injury or loss of life, or damage to equipment. | | | | |
| | DOUBLE INSULATION | | | | | |
| Ţ | PROTECTIVE (EARTH) TERMINAL | | | | | |

Introduction

Teledyne LeCroy PP019 and PP020 are passive high impedance voltage oscilloscope probes designed and calibrated for use with general purpose oscilloscopes having an input impedance of 1 M Ω shunted by 16 pF. However, they may be compensated for use with instruments having an input capacitance from 10 to 30 pF for PP019, and 8 to 20 pF for PP020. They are compatible with oscilloscopes that automatically detect probe attenuation and adjust their readout accordingly.



To avoid electric shock, keep fingers behind the probe's finger guard during use.



Rated for indoor use only. Do not operate where conductive pollutants may be present.

Specifications

| Model | Attn. | Input Impedance | | B/W | Rise Time | Length | Compensation Range |
|-------|-------|--------------------|-------|-------|--------------|--------|-----------------------|
| | | R (MΩ) | C(pF) | (MHz) | (ns) | (m) | (pF) |
| PP019 | 10x | 10 | 12 | 250 | 1.4 | 1.2 | 10 - 30 |
| PP020 | 10x | 10 | 11 | 500 | 0.7 | 1.2 | 8 - 20 |

Attenuation Ratio...... 10:1 ±1%

Max. Input Voltage...... Circuits not directly connected to Mains: 500 Vrms,

......1500 V transient overvoltage

...... Measurement Category II*: 400 Vrms



To reduce risk of fire or electric shock, do not exceed the voltage or category ratings of the probe. See voltage derating curve on p.4.

Pollution Degree 2*

Operating Altitude Up to 3000 meters

Max. Operating Temp...... 0 to 50 °C

Humidity...... 5% to 95% RH (10 to 30 °C)

5% to 75% RH (30 to 40 °C)

5% to 50% RH (above 40 °C)

RH not controlled below 10 °C


Definitions:

Measurement Category II (CAT II) refers to measurements performed on circuits directly connected to utilization points (socket outlets and similar) of the low-voltage mains installation.


Pollution Degree 2 refers to an operation environment where normally only dry non-conductive pollution occurs. Temporary conductivity caused by condensation must be expected.

^{*}As defined in IEC/EN 61010-031. See definitions below.


PP019 Input Impedance Profile



PP020 Input Impedance Profile



Voltage vs. Frequency Derating Curve



EC Declaration of Conformity

The product conforms to the applicable European Union requirements per Low Voltage Directive (LVD) 2014/35/EU. Compliance was demonstrated to the following specification as listed in the Official Journal of the European Communities:

IEC/EN 61010-031:2015 Safety requirements for electrical equipment for measurement, control and laboratory use – Part 031: Safety requirements for handheld probe assemblies for electrical measurement and test.

EU RoHS Compliance

The probe and accessories conform to the 2011/65/EU RoHS2 Directive.

Disposal



The probe complies with the applicable European Union requirements to Directives 2012/19/EU and 2013/56/EU on Waste Electrical and Electronic Equipment (WEEE) and Batteries.

General Safety Information



Observe generally accepted safety procedures in addition to those listed here to avoid personal injury or damage to equipment. The overall safety of any system incorporating this accessory is the responsibility of the assembler of the system.

Connect only to grounded instruments. Use only with compatible Teledyne LeCroy oscilloscopes that have their BNC input connected to an earth ground. Do not connect the probe reference lead to any point which is at a potential other than earth ground.

Connect and disconnect properly. Connect probe to the oscilloscope before connecting it to the test circuit. Disconnect the probe input and reference lead from the test circuit before disconnecting from the oscilloscope. Do not connect/disconnect probes while connected to a voltage source.

Do not overload. Do not apply any potential to the probe leads that exceeds the maximum rating of the probe. Observe all terminal ratings on the oscilloscope before connecting. Consult the oscilloscope product manual for further ratings information.

Always comply with the Voltage vs. Frequency Derating Curve.

Do not remove probe casing. Touching exposed connections may result in electric shock.

Use indoors only within operational environment listed. Do not use in wet or explosive atmospheres. Keep product surfaces clean and dry.

Handle with care. Probe tips are extremely sharp and may puncture skin or cause other bodily injury if not handled properly.

Keep fingers behind the finger guard of probe body and accessories.

Do not operate with suspected failures. Before each use, inspect the probe and accessories for any potential damage such as tears or other defects in the probe body, cable jacket, accessories, etc. If any part is damaged, cease operation immediately and sequester the probe from inadvertent use.

Cleaning

- Clean only the exterior of the probe, cables, and accessories. Use a soft cotton cloth moistened with a mild detergent and water solution.
 Do not allow any portion of the probe to be submerged at any time.
- Dry the probe and accessory thoroughly before attempting to make any voltage measurement.
- Do not subject the probe to solvents or solvent fumes as these can cause deterioration of the probe body, cables, and accessories.

Service

Refer all repairs to qualified service personnel. Contact Teledyne LeCroy at the following address to arrange to return the probe for service:

Teledyne LeCroy, Inc. 700 Chestnut Ridge Road Chestnut Ridge, NY, 10977-6499 Ph: 800-553-2769 or 845-425-2000 Fax: 845-578-5985 contact.corp@teledynelecroy.com


For the most complete and up-to-date list of sales and service centers by country, visit teledynelecroy.com/support/contact.

Probe Compensation

Proper compensation of the probe is required to assure amplitude accuracy of the waveform being measured by matching the probe to the oscilloscope's input capacitance. Compensation should be adjusted whenever the probe is connected to or transferred between oscilloscopes.

Low Frequency (PP019 and PP020)

- Apply a 1 kHz square wave to the probe or connect to the oscilloscope's calibrator output.
- Adjust the single LF trimmer on the PP019/20 BNC Compensation Box until you achieve a flat-topped square wave as in the center of the second illustration below.



LF trimmer on PP019 and PP020 BNC Compensation Box.




Over-compensated, correct, and under-compensated waveforms

High Frequency (PP020 Only)


High frequency should rarely require adjustment. However, if adjustment is required:

- 1. Apply a 1 MHz square wave to the probe (< 0.7 ns rise-time).
- 2. Remove the plastic caps from the two, HF trimmers on the PP020 BNC Compensation Box.




HF trimmers on PP020.

3. Adjust HF2 then HF1 until you achieve a flat-topped square wave as in the center illustration below.



Over-compensated, correct, and under-compensated waveforms

Replaceable Parts



| Item | Description | Quantity |
|------|-------------------------------|----------|
| 1 | Sprung Hook, 5 mm, Black | 1 |
| 2 | GND Lead w/Alligator Clip | 1 |
| 3 | BNC Adapter, 5 mm | 1 |
| 4 | Replacement Tip, Black | 1 |
| 5 | Deluxe Trimmer Tool | 1 |
| 6 | IC Tip Insulator, 5 mm, Black | 1 |
| 7 | Tip Insulator, 5 mm, Black | 1 |
| 8 | Identifier Rings | 1 |
| 9 | Probe Tip GND | 1 |

Standard Accessory Replacement Kit part number is PKIT4-5MM-101.

Warranty

NOTE: THE WARRANTY BELOW REPLACES ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS, OR ADEQUACY FOR ANY PARTICULAR PURPOSE OR USE. TELEDYNE LECROY SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER IN CONTRACT OR OTHERWISE. THE CUSTOMER IS RESPONSIBLE FOR THE TRANSPORTATION AND INSURANCE CHARGES FOR THE RETURN OF PRODUCTS TO THE SERVICE FACILITY. TELEDYNE LECROY WILL RETURN ALL PRODUCTS UNDER WARRANTY WITH TRANSPORT PREPAID.

Teledyne LeCroy warrants this oscilloscope accessory for normal use and operation within specification for a period of one year from the date of shipment. Spare parts, replacement parts and repairs are warranted for 90 days.

In exercising its warranty, Teledyne LeCroy, at its option, will either repair or replace any assembly returned within the warranty period to the Customer Service Department of an authorized service center. However, this will be done only if the product is determined by Teledyne LeCroy's examination to be defective because of workmanship or materials, and the defect is not caused by misuse, neglect, accident, abnormal conditions of operation; or, damaged by attempted repair or modifications by a non-authorized service facility.

The customer will be responsible for the transportation and insurance charges for the return of products to the service facility. Teledyne LeCroy will return all products under warranty with transportation charges prepaid.

This warranty replaces all other warranties, expressed or implied, including, but not limited to, any implied warranty of merchantability, fitness, or adequacy for any particular purposes or use. Teledyne LeCroy shall not be liable for any special, incidental, or consequential damages, whether in contract or otherwise.

928605-00 Rev A July, 2017