

Class R Fuseblocks Catalog Data

Catalog Number	Covers		Voltage	Current	Number of Poles	Label
Class R	w/o Indication	w/ Indication				
RM25100-1CR	CVR-RH-25100	CVRI-RH-25100	250	100	1	RM25100-1CR
RM25100-2CR					2	RM25100-2CR
RM25100-3CR					3	RM25100-3CR
RM25200-1CR	CVR-RH-25200	CVRI-RH-25200		200	1	RM25200-1CR
RM25200-2CR					2	RM25200-2CR
RM25200-3CR					3	RM25200-3CR
RM25400-1CR	CVR-RH-25400	CVRI-RH-25400		400	1	RM25400-1CR
RM25400-2CR					2	RM25400-2CR
RM25400-3CR					3	RM25400-3CR
RM25600-1CR	CVR-RH-25600	CVRI-RH-25600		600	1	RM25600-1CR
RM25600-2CR					2	RM25600-2CR
RM25600-3CR					3	RM25600-3CR

Catalog Number	Covers		Voltage	Current	Number of Poles	Label
Class R	w/o Indication	w/ Indication				
RM60100-1CR	CVR-RH-60100	CVRI-RH-60100	600	100	1	RM60100-1CR
RM60100-2CR					2	RM60100-2CR
RM60100-3CR					3	RM60100-3CR
RM60200-1CR	CVR-RH-60200	CVRI-RH-60200		200	1	RM60200-1CR
RM60200-2CR					2	RM60200-2CR
RM60200-3CR					3	RM60200-3CR
RM60400-1CR	CVR-RH-60400	CVRI-RH-60400		400	1	RM60400-1CR
RM60400-2CR					2	RM60400-2CR
RM60400-3CR					3	RM60400-3CR
RM60600-1CR	CVR-RH-60600	CVRI-RH-60600		600	1	RM60600-1CR
RM60600-2CR					2	RM60600-2CR
RM60600-3CR					3	RM60600-3CR

COOPER Bussmann
St. Louis MO 63178


TITLE:


Class R fuse holder-CUST


SCALE:
1:1

SIZE:
A3


SHEET:
1 OF 14














RM25100-3CR



RM25100-3CR WITH CVR-RH-25100 INSTALLED



RM25100-3CR WITH CVRI-RH-25100 INSTALLED



COOPER Bussmann
St. Louis MO 63178

TITLE:

Class R fuse holder-CUST-250V




SCALE:
1:1

SIZE:
A3



SHEET:
5 OF 14

RM25200-1CR



ALLEN KEY #:
3/8"(10.0MM)



RM25200-1CR WITH CVR-RH-25200 INSTALLED





CVR-RH-25200




RM25200-1CR WITH CVRI-RH-25200 INSTALLED

WARNING
TO AVOID ELECTRICAL
SHOCK, TURN
POWER OFF
BEFORE INSTALLING,
REMOVING OR
SERVICING.



CVRI-RH-25200




COOPER Bussmann
St. Louis MO 63178


Class R fuse holder-CUST-250V

SCALE: 1:1 SIZE: A3 SHEET: 6 OF 14







RM25200-2CR



RM25200-2CR WITH CVR-RH-25200 INSTALLED



RM25200-2CR WITH CVRI-RH-25200 INSTALLED



COOPER Bussmann
St. Louis MO 63178


TITLE:

Class R fuse holder-CUST-250V


SCALE:
1:1

SIZE:
A3


SHEET:
7 OF 14









RM25400-2CR



RM25400-2CR WITH CVR-RH-25400 INSTALLED



RM25400-2CR WITH CVRI-RH-25400 INSTALLED



REMOVE FOR WIRES
ABOVE 250 KCMIL

COOPER Bussmann
St. Louis MO 63178

TITLE:


Class R fuse holder-CUST-250V

SCALE:
1:1


SIZE:
A3

SHEET:
10 OF 14







RM25400-3CR




RM25400-3CR
WITH CVR-RH-25400 INSTALLED




RM25400-3CR
WITH CVRI-RH-25400 INSTALLED




RM25600-1CR





RM25600-1CR WITH CVR-RH-25600 INSTALLED




RM25600-1CR WITH CVRI-RH-25600 INSTALLED






WARNING
TO AVOID ELECTRICAL SHOCK, TURN POWER OFF BEFORE INSTALLING, REMOVING OR SERVICING.



CVR-RH-25600



CVRI-RH-25600



COOPER Bussmann
St. Louis MO 63178








Class R fuse holder-CUST-250V

SCALE: 1:1 SIZE: A3 SHEET: 12 OF 14

RM25600-2CR

RM25600-2CR WITH CVR-RH-25600 INSTALLED

RM25600-2CR WITH CVRI-RH-25600 INSTALLED




COOPER Bussmann
St. Louis MO 63178


TITLE:
Class R fuse holder-CUST-250V

SCALE: 1:1 SIZE: A3 SHEET: 13 OF 14







RM25600-3CR



RM25600-3CR WITH CVR-RH-25600 INSTALLED




RM25600-3CR WITH CVRI-RH-25600 INSTALLED



COOPER Bussmann
St. Louis MO 63178

TITLE:
Class R fuse holder-CUST-250V









SCALE: 1:1 SIZE: A3 SHEET: 14 OF 14



RM60100-2CR

RM60100-2CR
WITH CVR-RH-60100 INSTALLED

RM60100-2CR
WITH CVRI-RH-60100 INSTALLED



COOPER Bussmann
St. Louis MO 63178


TITLE:

Class R fuse holder-CUST-600V

SCALE:
1:1

SIZE:
A3

SHEET:
2 OF 12




COOPER Bussmann
St. Louis MO 63178

TITLE:

Class R fuse holder-CUST-600V

SCALE: 1:1
SIZE: A3
SHEET: 3 OF 12











St. Louis MO 63178

Class R fuse holder-CUST-600V

SCALE: 1:1

SIZE: A3

SHEET: 4 OF 12



 **COOPER Bussmann**
St. Louis MO 63178


TITLE:

Class R fuse holder-CUST-600V

SCALE:
1:

SIZE:
A3

SHEET:
5 OF 12





COOPER Bussmann
St. Louis MO 63178


TITLE:


Class R fuse holder-CUST-600V


SCALE: 1:1
SIZE: A3
SHEET: 6 OF 12














COOPER Bussmann
St. Louis MO 63178

TITLE:

Class R fuse holder-CUST-600V

SCALE: 1:5

SIZE: A3

SHEET: 12 OF 12