

Single Pedal Without Cover

LATCHING



Latching Operation - Push pedal to change contact state. When you release the pedal, the contacts remain in that state. Push again to return to original state.

ANALOG OUTPUT



Analog Output Operation - As the pedal is depress, voltage or amperage (depending on model) is increase. Features an additional programmable NP NO signaling contact that activates at a preset level.



| Single pedal foot switch F1 | | |
|-----------------------------|-------------|--------------------|
| Article number | Designation | Switching contacts |
| | | Pedal 1 |
| 616.1000.676 | F1-A2Y | 2NC |
| 606.1100.001 | F1-U1Y | 1NC / 1NO |

| Single pedal foot switch F1 | | |
|-----------------------------|-------------|--------------|
| Article number | Designation | Output Range |
| 616.1500.723 | F1-AU0-5 | 0 - 5 V |
| 616.1500.724 | F1-AU0-10 | 0 - 5 V |
| 616.1500.725 | F1-AI0-20 | 0 - 20 mA |
| 616.1500.726 | F1-AI4-20 | 4 - 20 mA |