



NOTES:

1. OPERATION

1. GENTLY LIFT LATCH AT SIDE OF CONNECTOR.
2. SWING COVER OFF OF CONTACTS.
3. SLIDE THE FLEX TAPE INTO THE CONNECTOR PLACING THE EDGE OF THE FLEX TAPE UNDER 2 HOLD DOWN TABS.
4. FOLD OVER THE COVER AND PRESS IN PLACE UNTIL THE LATCH IS FULLY ENGAGED.

2. LIMIT CURRENT TO A MAXIMUM OF 5 AMPS.

JKL PART NO.: ZCH-137HD-8J

			 THIRD ANGLE PROJECTION		DIMENSIONS ARE IN mm (INCHES) TOLERANCE UNLESS OTHERWISE SPECIFIED 1 PL +/- REF. 2 PL +/- REF. ANGLE +/-		 JKL COMPONENTS CORPORATION							
							TITLE NO SOLDER 8mm FLEX TAPE JOINER CONNECTOR							
A ADD SIDE VIEW RELEASE & CANCEL PL-1409-02			8/20/15 10/10/14		DRAWN BY L. WENGSTROM		APPV'D BY DATE L.R. 8/20/15		SIZE A		FSCM NO. 55335		DRAWING NO. ZCH-137HD-8J	
REV. NO. DESCRIPTION/ECO <small>ALL DIMENSIONS</small>			APPV'D DATE		- CAD DRAWING - MANUAL REVISIONS NOT PERMITTED		SCALE NONE		RELEASED DATE 10/10/14		REVISION DATE 8/20/15		REV. NO. A SHEET 1 OF 1	