




## Actuators and accessories





All these parts have to be ordered separately.

|   | Description<br>colour code                       | White<br>1 | Red<br>2 | Black<br>3 | Grey<br>4 | Green<br>5 | Blue<br>6 | Amber<br>7 | Yellow<br>8 | Pink<br>9 |
|---|--|------------|----------|------------|-----------|------------|-----------|------------|-------------|-----------|
|    | Standard paddle operator for 8H.<br>17 mm height | 8Z0001     | 8Z0002   | 8Z0003     | 8Z0004    | 8Z0005     | 8Z0006    | 8Z0007     | 8Z0008      |           |
|    | Short paddle operator for 8H.<br>14,5mm height   | 8Z0491     | 8Z0492   | 8Z0493     | 8Z0494    | 8Z0495     | 8Z0496    | 8Z0497     | 8Z0498      |           |
|     | Piano-key actuator for 8H                        | 8Z0121     | 8Z0122   | 8Z0123     | 8Z0124    | 8Z0125     | 8Z0126    | 8Z0127     | 8Z0128      |           |
|    | Paddle operator for 8HD                          | 8Z0431     | 8Z0432   | 8Z0433     | 8Z0434    | 8Z0435     | 8Z0436    | 8Z0437     | 8Z0438      |           |
|   | Paddle operator for 8M and 8V-M                  | 8Z0011     | 8Z0012   | 8Z0013     | 8Z0014    | 8Z0015     | 8Z0016    | 8Z0017     | 8Z0018      |           |
|  | Paddle operator for 8Q and 8V-Q                  | 8Z0051     | 8Z0052   | 8Z0053     | 8Z0054    | 8Z0055     | 8Z0056    | 8Z0057     | 8Z0058      |           |
|  | Rocker operator for 8H                           | 8Z0021     | 8Z0022   | 8Z0023     | 8Z0024    | 8Z0025     | 8Z0026    | 8Z0027     | 8Z0028      |           |
|  | Rocker operator for 8HD                          | 8Z0441     | 8Z0442   | 8Z0443     | 8Z0444    | 8Z0445     | 8Z0446    | 8Z0447     | 8Z0448      |           |
|  | Rocker operator for 8M and 8V-M                  | 8Z0031     | 8Z0032   | 8Z0033     | 8Z0034    | 8Z0035     | 8Z0036    | 8Z0037     | 8Z0038      |           |
|  | Rocker operator for 8X                           | 8Z0501     | 8Z0502   | -          | -         | 8Z0505     | 8Z0506    | 8Z0507     | 8Z0508      |           |
|   | Rocker operator for 8Q and 8V-Q                  | 8Z0071     | 8Z0072   | 8Z0073     | 8Z0074    | 8Z0075     | 8Z0076    | 8Z0077     | 8Z0078      |           |

|   | Description<br>colour code            | White<br>1         | Red<br>2   | Black<br>3 | Grey<br>4 | Green<br>5 | Blue<br>6 | Amber<br>7 | Yellow<br>8 | Pink<br>9 |
|---|---------------------------------------|--------------------|--|------------|-----------|------------|-----------|------------|-------------|-----------|
|    | Round tip lever sleeve for 8A, 8F, 8U | 8Z0111             | 8Z0112   | 8Z0113     | 8Z0114    | 8Z0115     | 8Z0116    | 8Z0117     | 8Z0118      | 8Z0119    |
|    | Cone tip lever sleeve for 8A, 8F, 8U  | 8Z0151             | 8Z0152   | 8Z0153     | 8Z0154    | 8Z0155     | 8Z0156    | 8Z0157     | 8Z0158      | 8Z0159    |
|    | Round tip lever sleeve for 8B         | 8Z0131             | 8Z0132   | 8Z0133     | 8Z0134    | 8Z0135     | 8Z0136    | 8Z0137     | 8Z0138      |           |
|   | Metal cap for 8E                      | (Silver)<br>8Z0091 | 8Z0092   | 8Z0093     | -         | -          | 8Z0096    | -          | -           |           |
|   |                                       |                    | 8Z0091 silver cap is supplied with the switch free of charge |            |           |            |           |            |             |           |
|  | Plastic cap for 8S                    | 8Z0511             | 8Z0512   | 8Z0513     | 8Z0514    | 8Z0515     | 8Z0516    | 8Z0517     | 8Z0518      |           |
|  | Rubber cap for 8A, 8F, 8U             | -                  | -  | 8Z0143     | -         | -          | -         | -          | -           |           |
|  | Plastic bezel for 8H, 8H-L            | 8Z0191             | 8Z0192   | 8Z0193     | 8Z0194    | 8Z0195     | 8Z0196    | 8Z0197     | 8Z0198      |           |
|  | Plastic bezel for 8X, 8K-L25          | 8Z0211             | 8Z0212   | 8Z0213     | 8Z0214    | 8Z0215     | 8Z0216    | 8Z0217     | 8Z0218      |           |
|  | Plastic bezel for 8W                  | 8Z0471             | 8Z0472   | 8Z0473     | 8Z0474    | 8Z0475     | 8Z0476    | 8Z0477     | 8Z0478      |           |

## Actuators

All these parts have to be ordered separately.

|   | Description<br>colour code   | White<br>1 | Red<br>2 | Black<br>3 | Grey<br>4 | Green<br>5 | Blue<br>6 | Amber<br>7 | Yellow<br>8 | Pink<br>9 |
|---|--|------------|----------|------------|-----------|------------|-----------|------------|-------------|-----------|
|  | Round 15 mm $\varnothing$<br>10 mm height button<br>for 8N, 8P, 8R | 8Z0061     | 8Z0062   | 8Z0063     | 8Z0064    | 8Z0065     | 8Z0066    | 8Z0067     | 8Z0068      |           |
|  | Round 10 mm $\varnothing$<br>8 mm height button<br>for 8N, 8P, 8R  | 8Z0081     | 8Z0082   | 8Z0083     | 8Z0084    | 8Z0085     | 8Z0086    | 8Z0087     | 8Z0088      |           |
|  | Round 9 mm $\varnothing$<br>3,5 mm height<br>button for 8Y         | 8Z0421     | 8Z0422   | 8Z0423     | 8Z0424    | 8Z0425     | 8Z0426    | 8Z0427     | 8Z0428      |           |
|  | Square button<br>for 8W  | 8Z0461     | 8Z0462   | 8Z0463     | 8Z0464    | 8Z0465     | 8Z0466    | 8Z0467     | 8Z0468      |           |