

---

### Main

Range of product	Altivar
Accessory / separate part category	Spare part
Accessory / separate part type	Control accessories
Accessory / separate part destination	Variable speed drive
Range compatibility	Altivar

---

### Complementary

---

### Environment

---

### Contractual warranty

Warranty period	18 months
-----------------	-----------

The information provided in this documentation contains general descriptions and/or technical characteristics of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric Industries SAS nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein.