

STANDARD KEYPAD LEGENDS

| | | | | | | | | | | | | |
|--------------------|----------------|--------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|---|----------------|-------------------|
| OPER 0 -0130 | 1 -0131 | ABC 2 -0132 | DEF 3 -0133 | GHI 4 -0134 | JKL 5 -0135 | MNO 6 -0136 | PRS 7 -0137 | TUV 8 -0128 | WXY 9 -0129 | | | |
| 0 -0100 | 1 -0001 | 2 -0002 | 3 -0003 | 4 -0004 | 5 -0005 | 6 -0006 | 7 -0007 | 8 -0008 | 9 -0009 | 10 -0010 | 11 -0011 | 12 -0012 |
| 13 -0013 | 14 -0014 | 15 -0015 | 16 -0016 | | | | | | | | | |
| A -0101 | B -0102 | C -0103 | D -0104 | E -0105 | F -0106 | G -0107 | H -0108 | I -0109 | J -0110 | K -0111 | L -0112 | M -0113 |
| N -0114 | O -0115 | P -0116 | Q -0117 | R -0118 | S -0119 | T -0120 | U -0121 | V -0122 | W -0123 | X -0124 | Y -0125 | Z -0126 |
| * -0215 | # -0216 | + -0205 | - -0206 | x -0207 | ÷ -0208 | . -0209 | = -0203 | % -0204 | → -0210 | Note: -0210 arrow can be inserted in in any of 4 directions | | ↕ -0217 |
| ALT -0347 | AUTO -0301 | CALL -0302 | CAN-CEL -0340 | CLEAR -0303 | CLR -0344 | DEC -0360 | DISK -0348 | DOWN -0304 | EDIT -0305 | EN-ABLE -0343 | END -0306 | ENT -0345 |
| ENTER -0307 | ERASE -0308 | EXIT -0309 | FREQ -0310 | FWD -0311 | GO -0312 | HOLD -0341 | HOST -0349 | IN -0313 | INC -0359 | INPUT -0314 | JOB -0351 | JOB -0352 |
| LOAD -0315 | LOCK -0357 | MAIN MENU -0354 | MAN -0358 | MENU -0316 | MODE -0317 | NEXT -0318 | OFF -0319 | ON -0320 | OUT -0321 | PREV -0356 | PRINT -0322 | PRO-GRAM -0323 |
| PWR -0324 | READ -0325 | RECV -0326 | REM -0355 | RE-SET -0327 | REV -0328 | ROLL -0353 | RUN -0329 | SAVE -0342 | SCAN -0330 | SEND -0331 | SET -0350 | SHIFT -0332 |
| SKIP -0333 | SRCH -0334 | START -0335 | STOP -0336 | STORE -0337 | TEST -0346 | UP -0338 | XMIT -0339 | | | | | |

Printed Button Availability

Most black on white, and white on black legends are stocked by distributors. For other color combinations allow time for delivery.

For local distributor contact Grayhill.

Printed Button Numbers

