



NOTES:

- 1. OPERATION
 - GENTLY LIFT LATCH AT SIDE OF CONNECTOR.
 - 2. SWING COVER OFF OF CONTACTS.
 - 3. SLIDE THE FLEX TAPE INTO THE CONNECTOR PLACING THE EDGE OF THE FLEX TAPE UNDER 2 HOLD DOWN TABS.
 - 4. FOLD OVER THE COVER AND PRESS IN PLACE UNTIL THE LATCH IS FULLY ENGAGED.
- 2. LIMIT CURRENT TO A MAXIMUM OF 5 AMPS.

JKL PART NO.: ZCH-143HD-8 I

			METRIC	DIMENSION IN mm (IN	-		IK	COMPON	JENTS COD	DOD AT	TON	
			$\left \bigoplus_{i=1}^{n} \right $	TOLERANCE UNLESS OTHERWISE SPECIFIED		COMPONENTS CORPORATION						
L	+		7	1 PL +/- REF. 2 PL +/- REF. ANGLE +/-		''''ב	NO SOLDER 8mm FLEX TAPE INPUT CONNECTOR					
\vdash			THIRD ANGLE PROJECTION									
\vdash				APPV'D BY	DATE	SIZE	FSCM NO.		ZCH-143H[)-8I		
r	RELEASE & CANCEL PL-1409-03	10/10/14					55335			T		
R	EV. DESCRIPTION/ECO	APPV'D	- CAD DRAWING - MANHAL REVISIONS NOT PERMITTED			SCALE		DATE 10/10/14	REVISION DATE	REV. NO.	1 of 1	