



**NOTES:**

**1. OPERATION**

1. GENTLY LIFT LATCH AT SIDE OF CONNECTOR.
2. SWING COVER OFF OF CONTACTS.
3. SLIDE THE FLEX TAPE INTO THE CONNECTOR PLACING THE EDGE OF THE FLEX TAPE UNDER 2 HOLD DOWN TABS.
4. FOLD OVER THE COVER AND PRESS IN PLACE UNTIL THE LATCH IS FULLY ENGAGED.

**2. LIMIT CURRENT TO A MAXIMUM OF 5 AMPS.**

**JKL PART NO.: ZCH-143HD-8I**

			<b>METRIC</b>  THIRD ANGLE PROJECTION		DIMENSIONS ARE IN mm (INCHES) TOLERANCE UNLESS OTHERWISE SPECIFIED 1 PL +/- REF. 2 PL +/- REF. ANGLE +/-		 <b>JKL COMPONENTS CORPORATION</b>					
							<b>TITLE</b> NO SOLDER 8mm FLEX TAPE INPUT CONNECTOR					
			DRAWN BY L. WENGSTROM		APPV'D BY DATE L.R. 10/10/14		SIZE <b>A</b>		FSCM NO. <b>55335</b>		DRAWING NO. <b>ZCH-143HD-8I</b>	
RELEASE & CANCEL PL-1409-03			10/10/14				SCALE NONE		RELEASED DATE 10/10/14		REVISION DATE	
REV. NO.			DESCRIPTION/ECO NUMBER		APPV'D DATE		- CAD DRAWING - MANUAL REVISIONS NOT PERMITTED		REV. NO.		SHEET 1 OF 1	