UNO-IPS 1560-AE

18-36 V_{DC} input/24 V_{DC} output, Uninterruptible Power Supply Module



Features

- Wide Range power input for 18-36 V_{DC}
- Metal enclosure supports different Book mounting position
- · Status indicators for monitoring battery pack and input power
- Free software utility for configuration and monitoring
- Over discharging & charging protection to extend battery life
- Metal enclosure supports Wall mount, Stand mount & DIN Rail mount
- Intelligently trigger PC shut down when power outage




Introduction

Intelligent UPS serves as a temporary power supply during short breaks in power and enables safe system shutdown. It can protect PC from electrical damage and greatly reduce the risk of losing data. The IPS module serves as temporary power during a short interruption in power and allows a safe system shutdown.


Specifications

Input	Input Voltage	18 -36 Vdc	
Output	Output Voltage	24Vdc +/-10%	
	Typical output current	3A (72W)	
Battery	Battery Capacity	14.4 V _{DC} , 1560 mAH	
	Cycle life	300 times of charge circle	
Protection	Short-circuit protection	Yes	
Certification	EMC	CE, FCC	
	Safety	UL, CB	
Dimensions (W x D x H)	55 x 86.6 x 21.4 mm		
Environment	Operating Temperature	0-45°C	
	Storage Temperature	$-20 \sim +50$ °C (less than 1 month) $-20 \sim +40$ °C (less than 3 months) $-20 \sim +20$ °C (less than 1 year)	
I/O Connectors	Monitor & Set IPS	RS-232	

User Scenario








Ordering Information


Part No.	Description	
UNO-IPS1560-AE	18-36 V_{DC} input/24 V_{DC} output, Uninterruptible Power Supply Module (Including control & power cable)	
UNO-2000G-DMKAE	DIN-Rail mounting kit for horizontal installation	
UNO-2271G-DMKAE	DIN-Rail mounting kit for vertical installation	

Mounting Illustration


Book Mount




DIN-Rail Mount (Vertical)



DIN-Rail Mount (Vertical)



I/O Appearance



- A: System Reset
- B: LED indicators:

LED	Bright(ON)	Dark(OFF)	Blinking
24V In	DC_IN	DC_IN loss	DC_IN loss over 5 minute, input step 2 (1Hz blinking)
Ready	System ready	System not work	NA
Batt. OK	BAT ready	not detect BAT	1. Low Battery (Note 1) 2. BAT abnormal (0.5Hz blinking) (Note 2)
Batt. Charge	NA	BAT no charging	1.BAT charging (1Hz blink) 2. BAT abnormal (0.5Hz blinking) (Note 2)

Note:

- 1. Low Battery
- BAT≦15%, BAT LED blinking , ≧16% return normal state
- 2. BAT abnormal

BAT temperature ≧60°C , BAT & CHG LED blinking (0.5Hz) , ≦55°C return normal state

- C: RS-232
- D: DC out (24V)
- E: DC In (18-36V)