

All dimensions are in mm.

COMPONENTS	MATERIALS	PLATING (μm)
Body	<b>STAINLESS STEEL</b>	<b>PASSIVATED</b>
Center contact	-	-
Outer contact	-	-
Insulator	-	-
Gasket	-	-
Others parts	-	-
-	-	-
-	-	-

PAGE 2/3

ISSUE **1334B**

SERIES **SMP**

PART NUMBER **R222450001**

## PACKAGING

Standard	Unit	Other
<b>100</b>	<b>Contact us</b>	<b>Contact us</b>

## ELECTRICAL CHARACTERISTICS

Impedance		<b>NA</b>	$\Omega$
Frequency		<b>NA</b>	GHz
VSWR	<b>NA</b>	<b>+</b>	<b>0.0000</b> x F(GHz) Maxi
Insertion loss		<b>NA</b>	$\sqrt{F}$ (GHz) dB Maxi
RF leakage	- (	<b>NA</b>	- F(GHz)) dB Maxi
Voltage rating		<b>NA</b>	Veff Maxi
Dielectric withstanding voltage		<b>NA</b>	Veff mini
Insulation resistance		<b>NA</b>	M $\Omega$ mini

## MECHANICAL CHARACTERISTICS

Center contact retention			
Axial force – Mating End		<b>NA</b>	N mini
Axial force – Opposite end		<b>NA</b>	N mini
Torque		<b>NA</b>	N.cm mini
Recommended torque			
Mating		<b>NA</b>	N.cm
Panel nut		<b>NA</b>	N.cm
Mating life		<b>100</b>	Cycles mini
Weight		<b>0.4200</b>	g

## ENVIRONMENTAL

Operating temperature	<b>-65/+165</b>	°C
Hermetic seal	<b>NA</b>	Atm.cm3/s
Panel leakage	<b>NA</b>	

## SPECIFICATION


## OTHER CHARACTERISTICS

Assembly instruction:

Others:

## ADDITIONAL INFORMATION MOUNTING INSTRUCTIONS

1. Check the quality of the soldering, as well as the position of the glass seal in the package .



2. Place the receptacle and pre-assemble screw on the package.

Mount the aligning tool R2821.860.020 into the flange to ensure a good concentricity.

Screw the receptacle on the package  
Remove the aligning tool.

