



## NOTES:

- 1. OPERATION
  - 1. GENTLY LIFT LATCH AT SIDE OF CONNECTOR.
  - 2. SWING COVER OFF OF CONTACTS.
  - 3. SLIDE THE FLEX TAPE INTO THE CONNECTOR PLACING THE EDGE OF THE FLEX TAPE UNDER 2 HOLD DOWN TABS. MAKE SURE THE POLARITY IS MATCHED BETWEEN THE FLEX TAPE AND THE CONNECTOR COVER.
  - 4. FOLD OVER THE COVER AND PRESS IN PLACE UNTIL THE LATCH IS FULLY ENGAGED.
- 2. LIMIT CURRENT TO A MAXIMUM OF 5 AMPS.
- 3. WILL WORK WITH 10mm OR 12mm WIDE FLEX RIBBON.

## JKL PART NO.: ZFS-CH144-12I

			METRIC	DIMENSIONS ARE IN mm (INCHES) TOLERANCE UNLESS		JKL COMPONENTS CORPORATION						
	<del> </del>	+	ļ	OTHERWISE 1 PL +/-	SPECIFIED REF.	TITLE	NO S	OLDER 12mi	n FLE	X TAPE	<b>=</b>	
			THIRD ANGLE PROJECTION	2 PL +/- ANGLE +/-		INPUT CONNECTOR						
Α	ADD NOTE 3 RELEASE & CANCEL PL-1206-02	10/8/13 3/5/13	DRAWN BY L. WENGSTROM	APPV'D BY L.R.	DATE 10/8/13	SIZE <b>A</b>		DRAWING NO.	ZFS-0	CH144	-12I	
REV.	DESCRIPTION/ECO NUMBER	APPV'D DATE	- CAD DRAWING - MANUAL REVISIONS NOT PERMITTED			SCALE	NONE	RELEASED 3/5/13	REVISION DATE	10/8/13	REV A	\$HEET 1 OF 1