Circuit Breaker for Equipment thermal, Snap-in type, Reset type, Quick connect terminals



Description

- Snap-in version
- Thermal circuit breaker
- 1-pole
- Reset type
- Quick connect terminals 6.3 x 0.8 mm

Unique Selling Proposition

- Compact design
- Positively trip-free release
- Available with cover
- Different mounting possibilities

Technical Data

Rated Voltage AC	AC 240 VAC
Rated Voltage DC	48 VDC
Rated current range AC	0.05 - 16 A
Conditional short circuit capa- city Inc	IEC 60934: PC1, AC 240 V: 2 kA
Short circuit capacity Icn	IEC 60934: at ln < 6.5 A/240 VAC : 8 x ln
_	IEC 60934: at ln ≥ 6.5 A/240 VAC : 96 A
Degree of Protection	from front side IP40 acc. to IEC 60529
Dielectric Strength	50Hz: > 1.5 kV
	Impulse 1.2/50 µs: > 2.5 kV
Insulation Resistance	$500 \text{ VDC} > 100 \text{ M}\Omega$
Endurance typical	2 x lr: 500 switching cycles
Endurance minimum	Reset type AC : $2 \times Ir$, $\cos \varphi 0.6$: DC : $2 \times Ir$, $L/R = 2 - 3 ms$: 50 switching cycles

Overload	IEC: min. 40 trips
	@ 6 x lr, cos q 0.6
	UL / CSA: min. 50 trips
	@ 1.5 x lr, cos φ 0.75
Allowable Operation Temp.	-5 °C to 60 °C
/ibration Resistance	± 1.5 mm @ 10 - 60 Hz
	acc. to IEC 60068-2-6, test Fc
	5 G @ 60 - 500 Hz
	acc. to IEC 60068-2-6, test Fc
Shock Resistance	100 G / 6ms
	acc. to IEC 60068-2-27, test Ea
Tripping Type	Thermal
Actuation Type	Reset type
Weight	ca. 10g

pdf data sheet, html datasheet, General Product Information, Distributor-

Stock-Check, Detailed request for product, Product News

Approvals and Compliances

Detailed information on product approvals, code requirements, usage instructions and detailed test conditions can be looked up in Details about Approvals

See below:

Weblinks

Applications - Power tools

Household EquipmentPower supplies and chargers

- Industrial appliances

Approvals and Compliances

SCHURTER products are designed for use in industrial environments. They have approvals from independent testing bodies according to national and international standards. Products with specific characteristics and requirements such as required in the automotive sector according to IATF 16949, medical technology according to ISO 13485 or in the aerospace industry can be offered exclusively with customer-specific, individual agreements by SCHURTER.

Approvals

The approval mark is used by the testing authorities to certify compliance with the safety requirements placed on electronic products. Approval Reference Type: T11

Approval Logo	Certificates	Certification Body	Description
NE	VDE Approvals	VDE	VDE Certificate Number: 99759
	UL Approvals	UL	UL File Number: E71572
	CCC Approvals	CCC	CCC Certificate Number: 2020970307003506

Product standards

Product standards that are referenced

Organization	Design	Standard	Description
IEC,	Designed according to	IEC 60934	Circuit-breakers for equipment (CBE)
(^U L)	Designed according to	UL 1077	Standard for Supplementary Protectors for Use in Electrical Equipment
GED CSA Group	Designed according to	CSA C22.2 No. 235	Supplementary Protectors
	Designed according to	GB 17701	Circuit-breaker for equipment

Application standards

Application standards where the product can be used


Organization	Design	Standard	Description
IEC	Designed for applications acc.	IEC/UL 62368-1	IEC 62368-1 includes the basic requirements for safety of audio, video, information technology and office equipment.


Compliances

The product complies with following Guide Lines

Identification	Details	Initiator	Description
CE	CE declaration of conformity	SCHURTER AG	The CE marking declares that the product complies with the applicable requirements laid down in the harmonisation of Community legislation on its affixing in accordance with EU Regulation 765/2008.
Rolls	RoHS	SCHURTER AG	Directive RoHS 2011/65/EU, Amendment (EU) 2015/863
60	China RoHS	SCHURTER AG	The law SJ / T 11363-2006 (China RoHS) has been in force since 1 March 2007. It is similar to the EU directive RoHS.
REACH	REACH	SCHURTER AG	On 1 June 2007, Regulation (EC) No 1907/2006 on the Registration, Evaluation, Authorization and Restriction of Chemicals 1 (abbreviated as "REACH") entered into force.

Dimension [mm]







T11-611 >7,5A



3

2






 a
 b

 0.8
 21,9

 1,0
 22,0

 1,5
 22,1

 0,0
 22,8




Typical internal resistance per pole

.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	unee her here
Rated Current [A]	Internal Resistance [Ω]
0.05	380.000
0.50	5.200
1.00	1.350
2.00	0.300
3.00	0.130
4.00	0.080
5.00	0.040
6.00	0.040
7.00	0.020
8.00	0.012
9.00	0.012
10.00	0.011
11.00	0.0095
12.00	0.0095
13.00	0.0085
14.00	0.0085
15.00	0.0075
16.00	0.0075

Time-Current-Curves

Time in Seconds



Reference Temperature +23°

Effect of ambient temperature

The units are calibrated for an ambient temperature of $+23^{\circ}$ C. To determine the rated current for a lower or higher ambient temperature, use a correction factor (typical value) from the table below:

Ambient Temperature [°C]	Correction factor
-5	0.87
0	0.90
+10	0.95
+23	1.00
+30	1.04
+40	1.10
+50	1.15
+60	1.20

Example: Rated current = 5 A, Environmental temperature = 40 °C, --> Correction factor = 1.1, Resulting current = 5.5 A --> Fount to next higher rated current: 6 A

Config. Code

T11 - 1 2 3 A B - 1.23

The characters are placeholders for the correspondingly keys of selections from the key tables.

key 0.9A 0.0A Shap-in mounting from front side 6 1.0 T11-123AB-1.23 = Actuation Type 1.1A 1 Actuation Type Configuration key 1.3A 1 Reset type 1 1.5A 1 T11-123AB-1.23 = Terminal 1.6A 1 Terminal Configuration key 1.9A 1 Quick connect terminal 6.3x0.8mm 1 2.0A 1 T11-123AB-1.23 = Shunt terminal 2.3A 2 2.3A 2 Shunt terminal Configuration key 2.3A 2 2.3A 2 Shunt terminal N 2.8A 2 2.3A 2 T11-123AB-1.23 = Setting indication 3.3A 3.3A 3.3A	ion key
Snap-in mounting from front side 0.9A 0.9A Snap-in mounting from front side 6 1.0 T11 1 2 3 A B 1 23 = Actuation Type 1.1A 1 Actuation Type Configuration key 1.3A 1 Reset type 1 1.5A 1 T11 1 2 3 A B 1 23 = Terminal 1.6A 1 Terminal Configuration key 1.8A 1 Quick connect terminal 6.3x0.8mm 1 1.9A 1 T11 1 2 3 A B 1 23 = Shunt terminal 2.0A 2 2 Shunt terminal Configuration key 2.3A 2 2 Shunt terminal Configuration key 3.3A 3 3.3A 3 Setting indication Configuration key 3.5A 3 3 3	0.8
1.0 T11 1 2 3 A B 1.23 = Actuation Type 1.1A 1 Actuation Type Configuration key 1.3A 1 Reset type 1 1.4A 1 T11 1 2 3 A B 1.23 = Terminal 1.6A 1 Terminal Configuration key 1.8A 1 Quick connect terminal 6.3x0.8mm 1 1.8A 1 T11 1 2 3 A B 1.23 = Shunt terminal 2.0A 2 2 Shunt terminal Configuration key 2.3A 2 2 Shunt terminal N 2.8A 2 2 T11 1 2 3 A B 1.23 = Setting indication N 3.5A 3	0.9
Actuation Type Configuration key 1.2A 1 Reset type 1 1.3A 1 T11 1 2 3 A B 1 23 = Terminal 1.6A 1 Terminal Configuration key 1.6A 1 Quick connect terminal 6.3x0.8mm 1 1.8A 1 T11 1 2 3 A B 1 23 = Shunt terminal 1 2.0A 1 Shunt terminal Configuration key 2.1A 2 Shunt terminal N 2.5A 2 Shunt terminal N 2.8A 2 Shunt terminal N 3.3A 3 Setting indication Configuration 3.5A 3	1
Actuation Type Configuration key 1.2A 1 Reset type 1 1.3A 1 T11 1 2 3 A B 1 23 = Terminal 1.6A 1 Terminal Configuration key 1.6A 1 Quick connect terminal 6.3x0.8mm 1 1.8A 1 T11 1 2 3 A B 1 23 = Shunt terminal 1 2.0A 1 Shunt terminal Configuration key 2.1A 2 Shunt terminal N 2.5A 2 Shunt terminal N 2.8A 2 Shunt terminal N 3.3A 3 Setting indication Configuration 3.5A 3	1.1
Key I.3A I.3A Reset type 1 1.4A 1 T11-12 3 A B - 1.23 = Terminal 1.6A 1 Terminal Configuration key 1.8A 1 Quick connect terminal 6.3x0.8mm 1 1.7A 1 T11-12 3 A B - 1.23 = Shunt terminal 1.9A 1 1 Shunt terminal Configuration key 2.1A 2 2 Shunt terminal N 2.8A 2 2 T11-12 3 A B - 1.23 = Setting indication 0.0A 3 3 3 Stug indication Configuration key 3.5A 3 3	1.2
Reset type 1 T11-12 3 A B - 1.23 = Terminal 1.4 A Terminal Configuration key Quick connect terminal 6.3x0.8mm 1 T11-12 3 A B - 1.23 = Shunt terminal 1.7 A Shunt terminal Configuration key Shunt terminal Configuration key Shunt terminal Configuration key Shunt terminal Configuration key Shunt terminal N T11-12 3 A B - 1.23 = Setting indication 3.3 A Setting indication Configuration key	1.3
1.5A 1 T11-12 3 A B - 1.23 = Terminal 1.6A 1 Terminal Configuration key 1.8A 1 Quick connect terminal 6.3x0.8mm 1 1.8A 1 T11-12 3 A B - 1.23 = Shunt terminal 1.8A 1 1.8A 1 Shunt terminal Configuration key 2.1A 2 2.3A 2 Shunt terminal N 2.5A 2 2.3A 2 T11-12 3 A B - 1.23 = Setting indication N 3.3A 3 3 Setting indication Configuration key 3.5A 3 3	1.4
Terminal Configuration key 1.7A 1 Quick connect terminal 6.3x0.8mm 1 1.8A 1 T11-12.3 A B - 1.23 = Shunt terminal 2.0A 2 2.0A Shunt terminal Configuration key 2.3A 2 2 Shunt terminal N 2.3A 2 2 Shunt terminal N 2.8A 2 2 Stunt terminal N 2.8A 2 2 Stunt terminal N 3.3A 3 3 Setting indication S.5A 3 3 3	1.5
Terminal Configuration key 1.8 Å 1.0 Å 1.0 Å 1.0 Å 1.0 Å 1.8 Å 1.0 Å 1.0 Å 1.0 Å 1.0 Å 1.0 Å 1.8 Å 1.8 Å <th1.8 th="" å<=""> <th1.8 th="" å<=""> 1.8 Å<th>1.6</th></th1.8></th1.8>	1.6
Number Numer Numer Numer <th>1.7</th>	1.7
Curck connect terminal 6.3x0.8mmIT11 - 1 2 3 A B - 1.23 = Shunt terminal2.0 AShunt terminalConfigurationShunt terminalNShunt terminalNT11 - 1 2 3 A B - 1.23 = Setting indication2.8 ASetting indication3.3 ASetting indication3.5 A	1.8
T11 - 123 A B - 1.23 = Shunt terminal 2.1 A 2 Shunt terminal Configuration key 2.3 A 2 Shunt terminal N 2.5 A 2 Shunt terminal N 2.8 A 2 T11 - 123 A B - 1.23 = Setting indication 3.3 A 3 Setting indication Configuration 3.5 A 3	1.9
Shunt terminalConfiguration key2.3 Å2Shunt terminalN2.5 Å2T11 - 1 2 3 Å B - 1.23 = Setting indication2.8 Å2Setting indication3.3 Å3Setting indication3.5 Å3	2
Shunt terminal Configuration key 2.5 A 2 Shunt terminal N 2.8 A 2 T11 - 1 2 3 A B - 1.23 = Setting indication 3.0 A 3.3 A 3 Setting indication Configuration 3.5 A 3	2.1
key2.5 Å2Shunt terminalN2.8 Å2T11 - 1 2 3 Å B - 1.23 = Setting indication3.0 Å3.0 ÅSetting indicationConfiguration3.5 Å3	2.3
T11 - 1 2 3 A B - 1.23 = Setting indication 3.0 A Setting indication 3.5 A	2.5
T11 - 1 2 3 A B - 1.23 = Setting indication 3.3A 3 Setting indication Configuration 3.5 A 3	2.8
Setting indication Configuration 3.5 A 3	3
Setung indication Configuration	3.3
key 4.0 A	3.5
	4
	4.5
T11 - 1 2 3 A B - 1.23 = Rated current	5
	5.5
Rated current Configuration 6.0 key 6.5 A 6	6
Key 6.5 A 6 0.05 A 0.05 7.0 A 6	6.5 7
	7.5
0.15 A 0.15 8.0 A	8
	B.5
0.3 A 0.3 9.0 A	9.5
	9.5
	10
	11
	12

Other rated currents on request

Other rated currents on request

Rated current	Configuration key	Rated current	Configuration key
13.0 A	13	15.0 A	15
14.0 A	14	16.0 A	16
Other rated currents on request		Other rated currents on request	

Variants

Rated current	Construction variants		Config. Code	Order Number
	Shunt terminal	Setting indication		
2.0 A			T11-611-2	4400.0002
10.0 A			T11-611-10	4400.0030
16.0 A			T11-611-16	4400.0034
3.5 A			T11-611-3.5	4400.0200

Most Popular.

Availability for all products can be searched real-time:https://www.schurter.com/en/Stock-Check/ Stock-Check-SCHURTER

Packaging Unit 100 Pcs